



SPRAY PAINTING FLASHINGS AT JOB END



Purpose:

To paint all visible flashings so the roof looks clean, finished, and professional.

Why This Is Important:

Unpainted flashings can look messy or stand out from the roof. Spray painting makes everything match and look great.

It's a small step that makes a big difference to our homeowners.

What Do We Paint?:

Only metal flashings that can be seen from the ground:

- Pipe boots
- Chimney flashings
- Roof to Wall flashing/Counter Flashing (unless it was ordered pre-painted)



Pipe Flashing



Vent Flashings



Counter Flashings



What You Need:

- Roof-safe spray paint (color to compliment shingles)
- Cardboard shield or other paint blocker
- A rag to wipe dust, mineral spirits or other cleaner to prepare flashings.
- Painters Tape/paper (optional, for tight areas and roof to wall flashings)
- Gloves



1 Clean the Area

- Use a rag to wipe off any dust on the flashing.
- Then use a cleaning solution/thinner to get the flashing ready for paint.
- Make sure it's dry before you paint.



2 Prepare for Spray Paint

- Cutout piece of cardboard or synthetic felt paper tight around penetration you are going to be painting to **protect shingles from paint**.
- Shake the can well before using. Keep shaking while you spray.



3 Spray Light Coats

- Hold the can 8 to 10 inches away from the metal.
- Spray using quick side-to-side motions.
- Use light coats so it doesn't drip.



4 Let It Dry & Check

- Let the paint dry for about 5 to 10 minutes.
- If it needs more, do a second light coat
- Look for any missed spots and touch them up



» Clean Up

- Wipe up any overspray with a rag and cleaner right away.
- Put spray cans and tools back in the truck.

- ✗ Don't:
- ✗ Don't paint when it's wet or raining
- ✗ Don't get spray paint on shingles or siding
- ✗ Don't leave drips or overspray



Spray Painting Flashings at Jobs End

Scan Code for Training Video

